



IF USE ONLY ALTERNAR SIGNAL CABLE

ADAPTER CABLE HARNESS ONLY IF:

THE SIGNAL OF THE ALTERNATOR IS USED WITHOUT THE KEY SIGNAL TO CONNECT THE TWO BATTERIES



DIFFERENCE BETWEEN NE185 AND NE355



USE THE ADAPTER WIRING TO CONNECT THE NE355 DERIVATOR

